


# HUMANE SLAUGHTER OF SHEEP



Electrode position  
(front view)



Electrode position  
(side view)



Stick position  
1 (recommended)  
2 (alternative)

**MINIMUM STUNNING CURRENT: 1 amp adult & 0.6 amp lambs**

**ELECTRODE APPLICATION TIME: NOT LESS than 3 seconds**

**STUN-TO-STICK TIME: LESS than 15 seconds**

Phase	Duration	Visible signs	Action
TONIC	10 to 20 sec	<ul style="list-style-type: none"> <li>&gt; animal collapses</li> <li>&gt; body becomes rigid</li> <li>&gt; no rhythmic breathing</li> <li>&gt; head raised</li> <li>&gt; hind legs flexed into body</li> </ul>	> stick during this phase if possible
CLONIC	15 to 45 sec	<ul style="list-style-type: none"> <li>&gt; involuntary kicking or paddling</li> <li>&gt; relaxation</li> </ul>	> stick immediately
RECOVERY	30 to 60 sec	<ul style="list-style-type: none"> <li>&gt; resumption of normal rhythmic breathing</li> <li>&gt; responds to painful stimuli</li> <li>&gt; becomes visually aware</li> <li>&gt; attempts to stand</li> </ul>	> stun with captive-bolt and stick immediately

For further information contact:

**Humane Slaughter Association**

The Old School, Brewhouse Hill, Wheathampstead, Herts AL4 8AN, UK

t: +44 (0)1582 831919 f: +44 (0)1582 831414 e: info@hsa.org.uk w: www.hsa.org.uk